

USER MANUAL

UVClean Tabletop Sanitizer[™] 120w Model: PT2120C

Please read instructions carefully before using. Keep instructions for reference before each use.

Set the timer, leave the room, remove all pets and plants and come back knowing germs are gone. Use for Home, Office, School, Restaurant, Clinics, Hospitals and more. Wherever there are germs, use your safe and effective UVClean Tabletop SanitizerTM 120w lamp.

Operating the UVCLean Tabletop Sanitizer™ 120w

- 1. Plug the Lamp into your wall socket.
- 2. To turn on the sterilizing lamp, press any timer button. Selections are 15, 30, 45 and 60 minutes.
- 3. Leave the room once you hear the "beep" that indicates the lamp timer cycle has begun. Once you hear a solid "beep", the lamp will turn on in 15 seconds and begin sterilizing.
- 4. When the pre-set time is complete, the lamp will automatically shut off.
- 5. You may enter the room after the lamp has been turned off and the timed cycle is complete.

Warranty: Product is covered under a 6-month replacement warranty against manufacturing defects. Warranty is null and void if the product is damaged physically by the consumer; the product is repaired, maintained, modified, and disassembled.

Wireless Remote Use

- 1. Download the "**Patriot UVCLean**" App from the Apple Store or Android Play Store. Follow the setup instructions.
- 2. Use either Bluetooth or Wifi to begin the sterilization cycle. Choose 15, 30, 45 or 60 minutes. Your selection will turn GREEN on the app.
- 3. Leave the room once you hear the "beep" that indicates the lamp timer cycle has begun. Once you hear a solid "beep", the lamp will turn on in 15 seconds and begin sterilizing.
- 4. When the pre-set time is complete, the lamp will automatically shut off.

Product Specifications

PT2120C
120W
6 x 8 x 28"
4.4 lb, 2 kg
Silver
Aluminum
8,000 hours
100-240V, 50/60Hz
253.7 nm
1300 ft2 (36 x 36ft); 120m² (11x11m)
On/Off Buttons, Remote Control via Bluetooth and WiFi

Disclaimers: **Sanitizing** UV-C lamps pose imminent danger if used without taking the proper precautions. You MUST avoid exposure to direct or reflected UV-C rays, since they cause painful eye irritation and reddening of the skin. Under no circumstances should any direct UV-C unit be permitted to operate with humans, animals or plants present in the operation area.